



REMOVE SCREWS FROM REAR ACCESS PANEL
REMOVE SCREWS FROM PERIMETER OF ENCLOSURE
SLIDE ENCLOSURE FORWARD OFF BASE

REAR WALL
NOTCHED
TO ALLOW
ENCLOSURE
TO SLIDE
FORWARD
OFF OF BASE

REMOVABLE BASE

REAR VIEW
11.75

OPENING IS WIDER THAN THE CONTROLLER

DUST FREE PC

DESCRIPTION	DRAWING
DFP201MDF51-FDF2	1238A
10/16/2019	SALES@DUSTFREEPC.COM
1-800-775-7611	WWW.DUSTFREEPC.COM